

ASBC Approved Methods – Conversion Tables

As-Is to Dry-Basis

As-Is

% Moisture

Result

Dry-Basis

Formula:

As-Is x 100 / 100-% Moisture

Example:

As-Is=77.7

Moisture= 5.0

Dry-Basis= 81.8