

ASBC Approved Methods Brewers' Grains – 3A

A. On sample in wet condition

Calculate loss in weight of wet grains as percent by the formula,

$$\text{Moisture, \%} = \frac{\text{loss in wt} \times 100}{\text{wt of sample}}$$

Moisture – Sample In Wet Condition

Wt of wet grains sample

Wt of dried sample

Results

Loss in wt

Moisture, %

$$\begin{aligned}\text{Moisture, \%} &= \frac{12.6320 \times 100}{14.8975} \\ &= 84.8\end{aligned}$$