

ASBC Approved Methods Brewers' Grains – 3D

D. On sample in wet condition – rapid method

Calculate loss in weight of wet grains as percent by the formula,

$$\text{Moisture, \%} = \frac{\text{loss in wt} \times 100}{\text{wt of sample}}$$

Moisture – Wet Condition Rapid Method

Wt of wet grains sample

Wt of dried sample

Results

Loss in wt

Moisture, %

$$\begin{aligned}\text{Moisture, \%} &= \frac{1.5909 \times 100}{2.0989} \\ &= 75.8\end{aligned}$$